

PETROCHEMICAL STORAGE TANK

SAFETY & PROTECTION

Пробоотборное устройство KSSD-A

Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Казахстан (7273)495-231

Таджикистан (992)427-82-92-69

Единый адрес для всех регионов: kcs@nt-rt.ru || <https://kspc.nt-rt.ru/>



SECTION 5.4_KSSD-A

SLOT DIPPING DEVICES

INTRODUCTION

 **The model KSSD-A** is designed for gauging the height of liquid levels, measuring the depth of water bottoms, taking temperature, and taking sample of liquids held in storage tank, without relieving pressure within the tank. It avoids the loss of valuable vapors, and exposing the gauger to excessive fumes. Quick opening valve unit is opened and closed simply by moving a lever through a 90° arc.

A by-pass is provided to equalize in the tank and sampling chamber unit, if this should be necessary for easy opening. The window in the top cover of the gauging unit can be provided with an inside wiper, to insure clear vision of the gauge taper, and to permit the taking of accurate reading.


Installation

- 1 Mount the KSSD-A Series Sampling Device on 4" or 8" flange roof nozzle.
- 2 Attach the gauging bob or sampling bottle to the swivel snap inside the sampling chamber unit.
- 3 Check the distance from the bottom of the bob to a point above the snap on the tape to make certain a correct reading is obtained.


Operation

-  1 Mount the Gauging the depth of the product.
- 2 Taking a sample at any level.
 - 3 Measuring the depth of water bottom.
 - 4 Measuring the product temperature.

APPLICATION



OUTLINE DRAWING



DIMENSION TABLE

SIZE	4"	6"	8"	10"	12"
N.D	100	150	200	250	300
PCD	190.5	241.3	298.4	361.9	431.8
OD	229	279	343	406	483
Approx. H	800	800	805	807	810
N - d	8 - 19	8 - 22	8 - 22	12 - 25	12 - 25

NOTE Standard Connection(ANSI 150LB flange) and JIS or different types are available upon request.

COMPONENT MATERIAL

ITEM NO	COMPONENT	BODY	ALUMINIUM	C.S	SS304
		TRIM	SS304	SS304	SS304
1	UPPER BODY		B26-319.F	A216-WCB	A351-CF8
2	LOWER BODY		B26-319.F	A216-WCB	A351-CF8
3	CAP		B26-319.F	A216-WCB	A351-CF8
4	PALLET		SS304	SS304	SS304
5	PALLET ARM		SS304	SS304	SS304
6	PALLET ARM STOPPER		N.B.R	N.B.R	N.B.R
7	PALLET HANDLE		SS304	SS304	SS304
8	COUNTER WEIGHT		A216-WCB	A216-WCB	A351-CF8
9	GASKET		NON-ASBESTOS	NON-ASBESTOS	NON-ASBESTOS
10	HEX BOLT		SS304	SS304	SS304
11	SEAL PLUG		SS304	SS304	SS304
12	PLUG SEATING		N.B.R	N.B.R	N.B.R

NOTE AL – Aluminium, C.S – Carbon Steel, S.S – Stainless Steel

По вопросам продажи и поддержки обращайтесь:

Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Казахстан (7273)495-231

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Таджикистан (992)427-82-92-69

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: kcs@nt-rt.ru || <https://kspc.nt-rt.ru/>

